



Rutland Maintenance Programme & Warranty.

Emergency Release TH.106

OPERATION:

- Push the Emergency doorstop till flush with the face plate
- This will release the door towards you for emergency entry
- To reset, depress the centre button to release the doorstop

MAINTENANCE (QUARTERLY):

- Check that the Emergency doorstop works freely and that all fixing screws are tight in the frame
- Lightly oil moving parts (including pivot sets in the door)

GAURANTEE & WARRANTY

- 25 Year mechanical warranty which excludes vandalism and misuse

Rutland Trading Co Limited

Whittington Way Chesterfield S41 9AG

t. +44 (0)1246 261491 | f. +44 (0)1246 264242 | e. sales@rutlanduk.co.uk | w. www.rutlanduk.co.uk

Registration number: 07594556 | Registration in England and Wales