


# Micro Rail Hold Open Device

FOR NON-FIRE DOOR APPLICATION

1

Slide the hold open clip into the micro rail, by removing the end cap, ensure the end cap is replaced once inserted.



2

Slide block with hold open clip back into the slide rail, then tighten using allen key and screw at desired angle of hold-open.

